




Welcome to Tech Repair Solutions

www.TechRepairSolutions.com

iPhone 12 12 Pro পাৰ্টস পৰিচিতি



iPhone 12, 12 Pro Inside

iPhone 12



iPhone 12 Pro



iPhone 12, 12 Pro LCD



iPhone 12 to 15 Pro Max opening Guide

Note: কখনই heat এবং Glue Removal Alcohol ছাড়া LCD খুলার চেষ্টা করবেন না।



Note: এখানে অনেক সতর্ক থাকতে হবে, কারণ Ear Speaker Flex টা অনেক ছোট।


Charging connector Side

Front camera Side

Left Side

Right Side

Ear Speaker Flex পরিচিতি ।



Front Camera Flex পরিচিতি ।

Infrared Camera

Front Camera

Dot Projector



Back Camera

iPhone 12



iPhone 12 Pro




Related problem

1. Camera black
2. Flash
3. Mic back

Wifi, Bluetooth Antenna পরিচিতি ।


Wifi Antenna



Wifi antenna Functions

- ❖ Wifi
- ❖ GPS
- ❖ NFC


Bluetooth Antenna




Bluetooth antenna Functions

- ❖ Bluetooth
- ❖ NFC

Flash light Flex পরিচিতি ।




Volume/Power Flex with Charging Inductor(Wireless Charger)



Functions

- Power Button
- Volume Up/Down
- Vibration Button
- Charging Inductor
- Wireless Charge


Charging Connector Section



Vibration Engine



Loud Speaker



Charging Connector

Charging Connector Section Functions

1. Charging Connector

Charging issues For Changing

- a. Charging cable Not connected
- b. Charging cable one side charging another side not charging
- c. Stop Charging when the cable is moving
- d. Apple Devices are not connected to the computer but Charging
- e. Reboot/Restart

2. Loud Speaker

3. Vibration engine

4. Mic bottom

5. Network/GSM antenna (Global system for mobile Communication)



Thank you Very Much

www.techRepairSolutions.com